Rev 1.0 05/08/2022		Checklist -	Aztec	(F) Flow)	(D) Do (M)	Memory
(D) Interior		Engine St	art (F)	Befo	re Take Of	ff (F)
AC Status MX and ARR	ROW	Brakes	Set	Crossfeed		Check
			As Required	<b>Engine Ga</b>		Check
Fuel Selector BOTH	ON	Throttle Controls	Open, 1"	Alternators	s	Check
Flaps CHE	CK	<b>Propeller Controls</b>	FORWARD	Autopilot		Check
Flap Lever	- Down	Mixture Controls	RICH	Cowl Flaps	S	Open
Hand Pump 16x (SLOWLY), The	en Stow	Fuel Pumps - On un	til Flow/ OFF	Mixture &	Propellers	Full
Gear Lever	Down	Magneto Switches	ON	Quadrant I	Friction	Set
Master Switch	ON	Propellers	Clear	Trim		Set
Gear Lights 3	Green	Engine Starter	Engage	Flaps		Verify
Fuel Qnty C	onfirm	Power	1000 RPM	Door		Locked
Fuel Pumps - CHECK THEN			Check	Icing Equi	•	As Required
Cowl Flaps		Vacuum	Check	Fuel Pump		ON
Alternator Inop Lights - CHE		Alternator	Check	Transpond	der	Set
Exterior Lights/Stall Horn -				Lights		ON
	DFF	Second Engine - Repe	_		Takeoff (F)	
		Mixtures	Set for Taxi		1500 RPM	
Mixture IDLE CUT-C		Avionics Master	ON	,	•	nents - Check
Trim Neuti	L	Flaps	Retract	Brakes - O		
Flight Contrls - FREE/CORF		Pre Taxi &Du		Throttles -		
		Lights	As Required	Power/Airs	•	eck
Emergency Exit Secu		Autopilot	Check, OFF	Rotate - Vr		
		Flight Instruments	Check	Landing G		UP
Exterior (D)		Crossfeed	Test	<b>O</b> II 1 (A		ITVE RATES
	heck		Crossfeed - Test		bove 1000	
	heck		Either Tank - OFF			4"/2500 RPM
X-feed Drain Check Drain		Engine Ru		Best Rate		- 103 kts
Right Wing Che		Parking Brake	Set	Engine Ins		Check
Windshield Che		Flight Controls	Free/Correct		s - As Requ	iired
Nose gear Che		Crossfeed	OFF	Lights - As	•	
33.3.		Fuel Tanks	Fullest	Fuel Pump		e at a Time
		Cabin Heater	Check	_	Cruise (F)	
Left Wing Che		Engine Temperature		Power	0 . 1	Set
Empennage Che	CK	Mixtures				
			Full Rich			9"/2200 RPM
Tie Downs Remov		Proppellers Fi	ull, High RPM	Engine Ins	truments	Check
Tie Downs Remov <u>Left &amp; Right Wings</u>		Proppellers For Propeller Sync	ull, High RPM Manual	Engine Ins Cowl Flaps	truments	Check As Required
Tie Downs Remov <u>Left &amp; Right Wings</u> Wing, Flap, Aileron Che	eck	Proppellers For Propeller Sync Engine Gauge	ull, High RPM Manual Check	Engine Ins Cowl Flaps Mixture	struments s	Check As Required Set
Tie Downs Remov <u>Left &amp; Right Wings</u> Wing, Flap, Aileron Che Tie-down Remov	eck ved	Proppellers Foundation Front Propeller Sync Engine Gauge Throttle S	ull, High RPM Manual Check Set 1500 RPM	Engine Ins Cowl Flaps Mixture	etruments s Descent (F	Check As Required Set
Tie Downs Remov <u>Left &amp; Right Wings</u> Wing, Flap, Aileron Che Tie-down Remov Fuel Caps Check Qty/S	eck ved Secure	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check	ull, High RPM Manual Check Set 1500 RPM Complete	Engine Ins Cowl Flaps Mixture Mixture	etruments s Descent (F	Check As Required Set ) h w/Descent
Tie Downs Remov <u>Left &amp; Right Wings</u> Wing, Flap, Aileron Che Tie-down Remov Fuel Caps Check Qty/S Langing Gear Che	eck ved Secure eck	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop	Engine Ins Cowl Flaps Mixture Mixture Power	etruments s Descent (F	Check As Required Set ) h w/Descent Set
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S Langing Gear Che Engine Inspection	eck ved Secure eck Check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM	Engine Ins Cowl Flaps Mixture Mixture Power AWOS	struments s <u>Descent (F</u> Enric	Check As Required Set  North W/Descent Set Reveive
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S Langing Gear Che Engine Inspection Fuel Sump - Drain	eck ved Secure eck Check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach	etruments s Descent (F Enric	Check As Required Set  h w/Descent Set Reveive Complete
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Tie-down Remove Fuel Caps Check Qty/S Langing Gear Cheft Engine Inspection Fuel Sump - Drain Engine Oil - 9 to 2	eck ved Secure eck Check n 3 sec 12 qts	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls Max	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps	etruments s Descent (F Enric Brief	Check As Required Set  Note: Set Set Reveive Complete Closed
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S Langing Gear Che Engine Inspection Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - C	eck ved Secure eck Check 13 sec 12 qts Check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls Max Man Press-Increase	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps	etruments s Descent (F Enric	Check As Required Set ) th w/Descent Set Reveive Complete Closed g (F)
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S Langing Gear Che Engine Inspection Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - C Pitot-Static (Left Wing)	eck ved Secure eck Check n 3 sec 12 qts Check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase N	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo	etruments s  Descent (F Enric  Brief s ore Landing	Check As Required Set ) th w/Descent Set Reveive Complete Closed g (F) Complete
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S Langing Gear Che Engine Inspection Fuel Sump - Drain Engine Oil - 9 to 2 Prop/Spinner - C Pitot-Static (Left Wing) C Before Engine Start (D)	eck ved Secure eck Check n 3 sec 12 qts Check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Before GUMPS Seats/Seats	Descent (F Enrice Brief s	Check As Required Set  h w/Descent Set Reveive Complete Closed g (F) Complete Secure
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Tie-down Remove Fuel Caps Check Qty/S Langing Gear Cheft Engine Inspection Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - C Pitot-Static (Left Wing) C Before Engine Start (D) Briefings Comp	eck ved Secure eck Check n 3 sec 12 qts Check Check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump	Descent (F Enrice Brief s	Check As Required Set  h w/Descent Set Reveive Complete Closed g (F) Complete Secure ON
Tie Downs Remove  Left & Right Wings  Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S  Langing Gear Che Engine Inspection  Fuel Sump - Drain Engine Oil - 9 to a Prop/Spinner - C  Pitot-Static (Left Wing) C  Before Engine Start (D)  Briefings Comp	eck ved Secure eck Check n 3 sec 12 qts Check Check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture	Descent (F Enrice Brief s	Check As Required Set ) th w/Descent Reveive Complete Closed g (F) Complete Secure ON Rich
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S Langing Gear Che Engine Inspection Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - O Pitot-Static (Left Wing) C Before Engine Start (D) Briefings Comp Doors Late Auxilary Latch Engage	eck ved Secure eck Check 12 qts Check Check check	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos  Max L/R Engine Instruments	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler	Descent (F Enrice Brief sore Landing	Check As Required Set ) th w/Descent Set Reveive Complete Closed g (F) Complete Secure ON Rich FWD
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Tie-down Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - CPitot-Static (Left Wing) CPItot-Static (Left Wing) CPITOTE Engine Start (D) Briefings Compute Doors Late Auxilary Latch Engages Seat, Seatbelts	eck ved Gecure eck Check 12 qts Check Check check check check ched aged cure	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos  Magnetos  Max L/R Engine Instruments Alternators	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture	Descent (F Enrice  Brief s Dre Landing t belts os	Check As Required Set ) th w/Descent Reveive Complete Closed g (F) Complete Secure ON Rich
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Tie-down Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - C Pitot-Static (Left Wing) C Before Engine Start (D) Briefings Computer Doors Late Auxilary Latch Engage Seat, Seatbelts Seat Parking Brake	eck ved Gecure eck Check 12 qts Check Check check check check ched aged cure	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos  Max L/R Engine Instruments	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Before GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Select	Descent (F Enrice Brief sore Landing t belts os	Check As Required Set ) h w/Descent Set Reveive Complete Closed g (F) Complete Secure ON Rich FWD Fullest Tank
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Tie-down Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - C Pitot-Static (Left Wing) C Before Engine Start (D) Briefings Compute Doors Late Auxilary Latch Engage Seat, Seatbelts Seat Parking Brake	eck ved Secure eck Check 12 qts Check Check check check check cycle cure Set	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos  Magnetos  Max L/R  Engine Instruments Alternators Vacuum	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befor GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed	Descent (F Enrice  Brief s ore Landing t belts os	Check As Required Set  h w/Descent Set Reveive Complete Closed g (F) Complete Secure ON Rich FWD Fullest Tank OFF
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Tie-down Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - Oiler Engine Start (D)  Before Engine Start (D) Briefings Compos Late Auxilary Latch Engane Seat, Seatbelts Seat Parking Brake Circuit Brakers Chemovers	eck ved Secure eck Check 12 qts Check Check check check check checd aged cure Set heck ON	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increas New Magnetos Max L/R Engine Instruments Alternators Vacuum Take Off Between Take Off Between Synchological New Magnetos New Mag	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps	Descent (F Enrice  Brief s ore Landing t belts os	Check As Required Set  Complete Closed  G (F)  Complete Secure ON Rich FWD Fullest Tank OFF As Required
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - Oiler Fuel Start (D) Briefings Comp Doors Late Auxilary Latch Engare Seat, Seatbelts Seat Parking Brake Circuit Brakers Chalternators Electrical Switch - As need	eck ved Secure eck Check 12 qts Check Check check check ON eded	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increase New Magnetos  Magnetos  Max L/R  Engine Instruments Alternators Vacuum  Take Off Be 1. Departure runway	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check riefing	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G	Descent (F Enrice  Brief s ore Landing t belts os	Check As Required Set  Net Set Reveive Complete Closed g(F) Complete Secure ON Rich FWD Fullest Tank OFF As Required on Below 132
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Remove Fuel Caps Check Qty/S Langing Gear Cheft Remove Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - CPI Prop/Spinner	eck ved Secure eck Check 12 qts Check Check check check Oheck check ON eded OFF	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls Max Man Press-Increas New Magnetos Max L/R Engine Instruments Alternators Vacuum Take Off Besides 1. Departure runway 2. Takeoff Distance	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check Tiefing	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps	Descent (F Enrice  Brief s ore Landing t belts os	Check As Required Set  Note Set Reveive Complete Closed g (F) Complete Secure ON Rich FWD Fullest Tank OFF As Required on Below 132 Set
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft ie-down Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - C Pitot-Static (Left Wing) C Before Engine Start (D) Briefings Comp Doors Late Auxilary Latch Engal Seat, Seatbelts Seat, Seatbelts Seat, Parking Brake Circuit Brakers Cheft Alternators Electrical Switch - As need Fuel Pumps & Crossfeed Cowl Flaps	eck ved Secure eck Check 12 qts Check Chec	Proppellers Propeller Sync Engine Gauge Throttle Feather Check Max Drop Throttles SPropeller Controls Max Man Press-Increa N Magnetos Max L/R Engine Instruments Alternators Vacuum Take Off B  1. Departure runway 2. Takeoff Distance 3. Accelerate STOP I	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check riefing	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befor GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps Heater	Descent (F Enrice Brief sore Landing t belts os tors	Check As Required Set  Note Set Reveive Complete Closed g (F) Complete Secure ON Rich FWD Fullest Tank OFF As Required In Below 132 Set FAN
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft and Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - Oiler Engine Start (D)  Before Engine Start (D) Briefings Compos Late Auxilary Latch Engate Seat, Seatbelts Seat, Seatbelts Seat, Seatbelts Seat, Seatbelts Seath Alternators Electrical Switch - As need Fuel Pumps & Crossfeed Cowl Flaps Oiler Cheever Seath Seater Cowl Flaps Oiler Composition Compositio	eck ved Secure eck Check 12 qts Check Chec	Proppellers Propeller Sync Engine Gauge Throttle Feather Check Max Drop Throttles SPropeller Controls Max Man Press-Increa N Magnetos  Max L/R Engine Instruments Alternators Vacuum Take Off B  1. Departure runway 2. Takeoff Distance 3. Accelerate STOP I 4. Speeds: Vr (65), C	Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check Tiefing Distance	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Select Crossfeed Cowl Flaps Landing G Flaps Heater Breaks	Descent (F Enrice  Brief s Descent (S Enrice  Brief s Dre Landing t belts Descent (F Enrice  Brief S Dre Landing T Down  Bync	Check As Required Set  Check Set Reveive Complete Closed G(F) Complete Secure ON Rich FWD Fullest Tank OFF As Required In Below 132 Set FAN Check
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - Of Prop/Spinner -	eck ved Secure eck Check 12 qts Check Chec	Proppellers Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls Max Man Press-Increa N Magnetos  Max L/R Engine Instruments Alternators Vacuum Take Off B 1. Departure runway 2. Takeoff Distance 3. Accelerate STOP I 4. Speeds: Vr (65), C 5. Heading/Alt or Nav	Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check Check riefing Distance	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps Heater Breaks Propeller S	Descent (F Enrice  Brief s Descent (S Enrice  Brief s Dre Landing State belts Ses  Sore Landing Ses Sore Landing Ses Sore Landing	Check As Required Set  Net Set Reveive Complete Closed G(F) Complete Secure ON Rich FWD Fullest Tank OFF As Required IN Below 132 Set FAN Check Manual
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - C Pitot-Static (Left Wing) C Before Engine Start (D) Briefings Comp Doors Late Auxilary Latch Enga Seat, Seatbelts Seat Parking Brake Circuit Brakers Cheft Alternators Electrical Switch - As need Fuel Pumps & Crossfeed Cowl Flaps OHeater Chemover Check Composite Composi	eck ved Secure eck Check 12 qts Check Check Check Check ON eded OFF OFF ON	Proppellers Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls Max Man Press-Increa N Magnetos Max L/R Engine Instruments Alternators Vacuum Take Off B 1. Departure runway 2. Takeoff Distance 3. Accelerate STOP I 4. Speeds: Vr (65), C 5. Heading/Alt or Nav 6. Engine Failure Pro	Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check Check riefing Distance	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps Heater Breaks Propeller S Landing Li	Descent (F Enrice  Brief s Descent (S Enrice  Brief s Dre Landing s Sere Landing	Check As Required Set  Net Set Reveive Complete Closed g (F) Complete Secure ON Rich FWD Fullest Tank OFF As Required n Below 132 Set FAN Check Manual ON
Tie Downs Remove Left & Right Wings Wing, Flap, Aileron Cheft and Remove Fuel Caps Check Qty/S Langing Gear Cheft Sump - Drain Engine Oil - 9 to Prop/Spinner - Oiler Engine Start (D) Briefings Computer Doors Late Auxilary Latch Engage Seat, Seatbelts Seat, Seatbelts Seat, Seatbelts Seat, Seatbelts Seat, Seatbelts Seather Seather Circuit Brakers Cheft Alternators Electrical Switch - As near Fuel Pumps & Crossfeed Cowl Flaps Oheater Computer Switch & Beacon Gear Lights Check 3 G	eck ved Secure eck Check 12 qts Check check check check ON eded OFF OFF ON Green	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increas New Magnetos Max L/R Engine Instruments Alternators Vacuum Take Off Besides 1. Departure runway 2. Takeoff Distance 3. Accelerate STOP Is 4. Speeds: Vr (65), Ces 5. Heading/Alt or Nav 6. Engine Failure Promote Before Take	ull, High RPM Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check riefing Distance	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps Heater Breaks Propeller S Landing Li Approach	Descent (F Enrice  Brief s Descent (S Enrice  Brief s Dre Landing s Sere Landing	Check As Required Set  Net Note the wide secure Complete Closed G(F) Complete Secure ON Rich FWD Fullest Tank OFF As Required on Below 132 Set FAN Check Manual ON 100 Kts
Tie Downs  Left & Right Wings  Wing, Flap, Aileron Che Tie-down Remov Fuel Caps Check Qty/S  Langing Gear Che Engine Inspection  Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - 0  Pitot-Static (Left Wing) C  Before Engine Start (D)  Briefings Comp Doors Lato Auxilary Latch Enga Seat, Seatbelts Seat Parking Brake Circuit Brakers Che Alternators Electrical Switch - As nea Fuel Pumps & Crossfeed Cowl Flaps O Heater (Comp De-ice (Comp Master Switch & Beacon Gear Lights Check 3 G Door Ajar Light	eck ved Secure eck Check 12 qts Check Chec	Proppellers For Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seather Controls Max Man Press-Increas New Magnetos Max L/R Engine Instruments Alternators Vacuum Take Off Belief Distance 3. Accelerate STOP Idea Speeds: Vr (65), Celegine Failure Probe Before Take Briefing	Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check Check Tiefing  Distance Llimb 103 Cedures Off (F) Complete	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befor GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps Heater Breaks Propeller S Landing Li Approach Threshold	Descent (F Enrice  Brief s Descent (F Enrice  Brief s Dre Landing t belts Dre Landing	Check As Required Set  Net Note Complete Closed G(F) Complete Secure ON Rich FWD Fullest Tank OFF As Required In Below 132 Set FAN Check Manual ON 100 Kts 70-80 Kts
Tie Downs  Left & Right Wings  Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S  Langing Gear Che Engine Inspection  Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - C  Pitot-Static (Left Wing) C  Before Engine Start (D)  Briefings Comp Doors Lato Auxilary Latch Enga Seat, Seatbelts Seat Parking Brake Circuit Brakers Check Alternators Electrical Switch - As need Fuel Pumps & Crossfeed Cowl Flaps O Heater Cowledge Master Switch & Beacon Gear Lights Check 3 G Door Ajar Light Mixture Controls Cut-	eck ved Secure eck Check 12 qts Check Chec	Proppellers Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls Max Man Press-Increa N Magnetos  Max L/R Engine Instruments Alternators Vacuum Take Off B 1. Departure runway 2. Takeoff Distance 3. Accelerate STOP I 4. Speeds: Vr (65), C 5. Heading/Alt or Nav 6. Engine Failure Pro Before Take Briefing Seats & Seat Belts	Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Che	Engine Ins Cowl Flaps Mixture  Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps Heater Breaks Propeller S Landing Li Approach Threshold  Vr 65  VY 103	Descent (F Enrice  Brief s Descent (S Enrice  Brief s Dre Landing t belts s tors s ear- Down  Sync ights Speed Speed VA 131 Vno 175	Check As Required Set  Net Note the Widescent Set Reveive Complete Closed G(F) Complete Secure ON Rich FWD Fullest Tank OFF As Required on Below 132 Set FAN Check Manual ON 100 Kts 70-80 Kts fe141/123/108 Vs1 547
Tie Downs  Left & Right Wings  Wing, Flap, Aileron Che Tie-down Remove Fuel Caps Check Qty/S  Langing Gear Che Engine Inspection  Fuel Sump - Drain Engine Oil - 9 to Prop/Spinner - O  Prop/Spinner - O  Pitot-Static (Left Wing) C  Before Engine Start (D)  Briefings Comp Doors Lato Auxilary Latch Enga Seat, Seatbelts Seat Parking Brake Circuit Brakers Check Seat Alternators Electrical Switch - As near Fuel Pumps & Crossfeed Cowl Flaps O Heater Comp De-ice Master Switch & Beacon Gear Lights Check 3 G Door Ajar Light Mixture Controls Cut-	eck ved Secure eck Check 12 qts Check check Check Oneck OFF OFF OFF OFF OFF OFF	Proppellers Propeller Sync Engine Gauge Throttle Seather Check Max Drop Throttles Seropeller Controls Max Man Press-Increa N Magnetos Max L/R Engine Instruments Alternators Vacuum Take Off B 1. Departure runway 2. Takeoff Distance 3. Accelerate STOP I 4. Speeds: Vr (65), C 5. Heading/Alt or Nav 6. Engine Failure Pro Before Take Briefing Seats & Seat Belts Door	Manual Check Set 1500 RPM Complete - 500 RPM Drop Set 2200 RPM Exercise Drop - 300 RPM ase/Oil Decrease o visible Oil On Cowl Check Max Drop - 175 RPM Difference - 50 RPM Check Check Check riefing Distance Climb 103 Cedures Off (F) Complete Secure	Engine Ins Cowl Flaps Mixture Mixture Power AWOS Approach Cowl Flaps Befo GUMPS Seats/Seat Fuel Pump Mixture Propeler Fuel Selec Crossfeed Cowl Flaps Landing G Flaps Heater Breaks Propeller S Landing Li Approach Threshold Vr 65	Descent (F Enrice  Brief s Descent (S Enrice  Brief s Dre Landing  t belts Descent (F Enrice  Brief S Dre Landing  t belts Descent (F Enrice  Brief S Dre Landing  t belts Descent (F Enrice  Brief S Dre Landing  t belts Descent (F Enrice  Enrice  Brief S Dre Landing  t belts Descent (F Enrice  Enrice  Brief S Descent (F Enrice  Enric	Check As Required Set  Net Note the Widescent Reveive Complete Closed G(F) Complete Secure ON Rich FWD Fullest Tank OFF As Required In Below 132 Set FAN Check Manual ON 100 Kts 70-80 Kts